DELTONS RK202 INSTALLATION GUIDE

1 Mounting

Junction box not included

Gasket optional

ESD
ATTENTION
Observe precautions for handling
ELECTROSTATIC SENSITIVE DEVICES

3 Install Reader to Backplate

2 Wiring

Red == +12V

Black == GND

Green == D0

Yellow == D1

Grey == Led

18 in (0.46 m)

To Main Controller

4 Power & Testing

Turn on power

Test card

RK202 13.56 MHz Card Reader